


(1) Locate Switches S1 Thru S32 On MPU Assembly.

(2) Set Switches For Desired Game Conditions.

(3) Turn Game Off, Then On. Adjustments Are Then Complete.

| Game Adjustments | Switch No. | Switch Function               | Game Function |
|------------------|------------|-------------------------------|---------------|
| CHIME MELODY     | S-8        | ON — ON<br>OFF — OFF          |               |
| BALLS PER GAME   | S-7        | ON — 5 BALLS<br>OFF — 3 BALLS |               |
| CREDIT DISPLAY   | S-20       | ON — ON<br>OFF — OFF          |               |
| MATCH FEATURE    | S21        | ON — ON<br>OFF — OFF          |               |

12A-156



Font used: Helvetica, CentSchbook Mono BT.  
Card size: 197 x 95 mm

Card 12A-156 confirmed.

Enjoy and have fun,  
Peter

[www.inkochnito.nl](http://www.inkochnito.nl)

If you like my work, please send me a donation via PayPal.