

TO REMOVE BACKBOX

- 1) DISCONNECT CABINET & PLAYFIELD CABLES, AND GROUND STRAP.
- 2) REMOVE TOP WOOD SCREW AND PIVOT WOOD BLOCK.
- 3) SLIDE ENTIRE BACKBOX TO RIGHT, OFF HINGE.

TO REMOVE BACKBOX

- 1) DISCONNECT CABINET & PLAYFIELD CABLES, AND GROUND STRAP.
- 2) REMOVE TOP WOOD SCREW AND PIVOT WOOD BLOCK.
- 3) SLIDE ENTIRE BACKBOX TO RIGHT, OFF HINGE.

Fonts used: News Gothic MT Std.

Cards status:

To Remove Backbox card confirmed (no card number).

The card on the right is a scan of the original (older type) card.

If you have any other information about these cards, please send a readable picture or scan to me.

Enjoy and have fun,
Peter

www.inkochnito.nl

If you like my work, please send me a donation via PayPal.