

METEOR SELF TEST DISPLAY NUMBERS

SELF TEST

BUTTON LOCATED INSIDE OF COIN DOOR


NO. OF TIMES PUSHED	TEST	DESCRIPTION
1	BURN IN	All outputs tested.
2	LAMPS	All feature lamps will flash on & off.
3	DISPLAY	All digits display 000000 thru 999999 then No. 8 shifts from left to right.
4	SOLENOIDS	Continuous sequence of solenoids pulsed, then all sounds pulsed. (Solenoid driver transistor "Q" number displayed as solenoid is pulsed.)
5	SWITCHES (Flashing 0 if all switches open)	Switch I.D. No. displays if closed (See chart for switch I.D. No.)
6 To 23	THRESHOLD & BOOKKEEPING	See Operating Manual

SOLENOID IDENTIFICATION

SOLENOID NO.	SOLENOID LOCATION
01	THUMPER BUMPER
02	LEFT SLING-SHOT
03	KNOCKER
04	3-BANK DROP TARGET (LEFT BOTTOM)
05	3-BANK DROP TARGET (LEFT TOP)
06 thru 11	6-BANK DROP TARGETS
12	6-BANK DROP TARGET (Reset)
13	3-BANK DROP TARGET (Right)
14	RIGHT SLING-SHOT
15	FLIPPERS
16	OUT-HOLE
19	COIN LOCK-OUT
20 thru 29	SOUND

SWITCH IDENTIFICATION

SWITCH NO.	SWITCH LOCATION	SWITCH NO.	SWITCH LOCATION
01	COIN CHUTE { SEE	18	OPEN
02	COIN CHUTE { DRWG.	19-21 ...	3-BANK DROP TARGET (TOP LEFT)
03	COIN CHUTE { BELOW	22-24 ...	3-BANK DROP TARGET (LEFT CENTER)
04	STAND-UP TARGET	25	OPEN
05	SPIN TARGET	26	OPEN
06	CREDIT BUTTON	27-32 ...	6-BANK DROP TARGETS
07	TILTS	33	OUT-HOLE
08	SLAM & VIB. TILTS	34	RIGHT OUT-LANE
09-11 ...	3-BANK DROP TARGET (RIGHT)	35	LEFT OUT-LANE
12	BUMPER (UPPER RIGHT)	36	RIGHT RETURN LANE
13	BUMPER (UPPER LEFT)	37	LEFT RETURN LANE
14	THUMPER BUMPER	38	ROLL-OVER BUTTON (UPPER)
15	RIGHT SLING-SHOT	39	ROLL-OVER BUTTON (CENTER)
16	LEFT SLING-SHOT	40	ROLL-OVER BUTTON (LOWER)
17	OPEN		



NOTE: FLIPPER BUTTON CABINET SWITCHES DO NOT APPEAR ON TEST

Font used: HelveticaNeueLT Std Thin, Helvetica, Helvetica-Condensed, Futura Std ExtraBold
Self Test card 12C-264-4 (size 140 x 280 mm) confirmed.

Enjoy and have fun,
Peter

www.inkochnito.nl

If you like my work, please send me a donation via PayPal.