

WORLD CUP '94

- GOAL:** Shoot GOAL whenever Soccer Ball is Spinning!
Complete Rollover Buttons to re-light Goal.
- ULTRA:** Each GOAL lights an ULTRA FEATURE for High Scoring.
- T.V.:** T.V. is lit every 4 GOALS for Timed Feature.
- LOCK:** Shoot flashing "BUILD" shots to complete Soccer Ball and Light Locks on Both Ramps.
- MULTI-BALL™:** Shoot Final Draw hole to begin Multi-ball™.
- JACKPOT:** Goals in Multi-ball™ score Jackpot and advance Rank.
Shoot either Ramp to re-light Goal Jackpot.
- CITIES:** Buy Tickets by completing Top Lanes or both Ramps.
Shoot Spinner Lane to travel to flashing city.
Travel to Boston for Tea Party (Hurry Up).
Travel to Washington D.C. to Light Extra Ball.
Travel to Los Angeles for World Cup Final Match.
- STRIKER:** Shoot Top Center Hole to collect random STRIKER Award.
Spell S-T-R-I-K-E-R by hitting Striker's Targets.
- SKILL SHOT:** Complete all 3 lanes to collect 30 Million and advance 1 City.



C1992 WC'94/ISL