

FREEDOM

SELF-TEST DISPLAY NUMBERS

SWITCH ASSEMBLY IDENTIFICATION

<u>SWITCH SELF- TEST #</u>	<u>SWITCH DESCRIPTION</u>	<u>SWITCH SELF- TEST #</u>	<u>SWITCH DESCRIPTION</u>
01	DROP TARGET 1	17	
02	DROP TARGET 2	18	LEFT & RIGHT OUT
03	DROP TARGET 3	19	SCORE 100 (GP)*
04	DROP TARGET 4	20	SCORE 10 (GP)*
05	DROP TARGET 5	21	WHEEL ROLLOVER
06	CREDIT BUTTON	22	ADVANCE BONUS*
07	TILT	23	SPINNER
08	OUTHOLE	24	COLLECT WHEEL
09	COIN III	25	
10	COIN I	26	
11	COIN II (IF USED)	27	
12		28	RIGHT SLING SHOT
13		29	BUMPER #3
14		30	BUMPER #2
15		31	BUMPER #1
16	SLAM	32	LEFT SLING SHOT

* GENERAL PURPOSE OR MULTIPLE

SOLENOID ASSEMBLY IDENTIFICATION

<u>SOLENOID SELF-TEST #</u>	<u>SOLENOID IDENTIFICATION</u>
01	OUTHOLE
02	KNOCKER
03	SAUCER (SCORES WHEEL VALUE)
04	TOP HOLE
05	CHIME 10
06	CHIME 100
07	CHIME 1000
08	EXTRA CHIME
09	#1 THUMPER-BUMPER (TOP)
10	#2 THUMPER-BUMPER
11	#3 THUMPER-BUMPER
12	LEFT SLING SHOT
13	RIGHT SLING SHOT
14	DROP TARGET RESET
15	COIN LOCK -OUT
16	K1 RELAY (FLIPPER ENABLE)

AWARD THRESHOLD ADJUSTMENTS

HIGH SCORE FEATURE: Three Score Thresholds-Free Game for each.

RECOMMENDED THRESHOLDS:	1st	2nd	3rd
3-BALL	100,000	134,000	168,000
5-BALL	116,000	138,000	170,000

- 1) **VIEW** Threshold: Push and release Red Self-Test button inside door (approx. 11X). Number 07 (1st), 08 (2nd), 09 (3rd) appears on Match/Ball in Play display.
- 2) **CHANGE** Threshold: Press Credit Button on door. Release when desired threshold appears.
- 3) **DISABLE** Threshold (any one or all): Do 1). Push S33 on MPU assembly in backbox. '00' appears on player score displays.
- 4) **RESET AND CHANGE** Threshold: Do 1), 3) and 2).

HIGH GAME FEATURE: Awards three free games.

RECOMMENDED THRESHOLD: 180,000

- 1) **VIEW** Threshold: Same as 1) above, look for number '10'.
- 2) **CHANGE** Threshold: Same as 2) above.
- 3) **RESET AND CHANGE:** Same as 4) above.

-7

HIGH GAME FEATURE: 3 FREE GAMES FOR BEATING HIGH GAME TO DATE.
ON - SET S15 to ON. **OFF** - SET S15 to OFF.

HIGH SCORE FEATURE: AWARD AT EACH OF 3 PRESET LEVELS.
FREE GAME: SET S6 to ON.
EXTRA BALL: SET S6 to OFF.

FREEDOM WHEEL ARROW: ROTATE CONTINUOUSLY: SET S7 to ON.
ADVANCE WITH TENS: SET S7 to OFF.

DROP TARGET NOVELTY OPTION (SCORE AWARD) SET S22 to ON
SPECIAL FEATURE: NON-NOVELTY OPTION (BALL/GAME AWARD) SET S24 to ON.

REPLAY OPTION: SET S23 to ON.
EXTRA BALL OPTION: SET S23 to OFF.
LIBERAL AWARD OPTION: SET S24 to ON.
CONSERVATIVE AWARD OPTION: SET S24 to OFF.

-5

Font used: AlternateGotNo2D, Helvetica CE

Cards status:

Card-6 Self-Test Display Numbers confirmed.

Card-7 Award Threshold confirmed.

Card-5 High Game Feature confirmed.

If you have any other information about these cards, please send a readable picture or scan to me.

Enjoy and have fun,

Peter

www.inkochnito.nl

If you like my work, please send me a donation via PayPal.