

<u>GAME ADJUSTMENTS:</u>	(1)	LOCATE SWITCHES S1 THRU S32 ON MPU ASSEMBLY A4.
	(2)	SET SWITCHES FOR DESIRED PLAYFIELD CONDITIONS.
	(3)	TURN GAME OFF. THEN ON. ADJUSTMENTS ARE THEN COMPLETE.
<u>BALLS PER GAME:</u>	5-BALL	- SET S31 TO ON. S32 TO OFF.
	4-BALL	- SET S31 TO OFF. S32 TO ON.
	3-BALL	- SET S31 TO OFF. S32 TO OFF.
	2-BALL	- SET S31 TO ON. S32 TO ON.
<u>SOUND OPTION:</u>	(REFER TO INSTRUCTION MANUAL PAGE 7).	
<u>MATCH FEATURE:</u>	ON	- SET S28 TO ON.
	OFF	- SET S28 TO OFF.
<u>CREDIT DISPLAY:</u>	DISPLAY ON	- SET S27 TO ON.
	DISPLAY OFF	- SET S27 TO OFF.

M-051-00365-A005

Font used: Courier Prime
M-051-00365-A005 Game Adjustments (size 184 x 76 mm) confirmed.

Enjoy and have fun,
Peter

www.inkochnito.nl

If you like my work, please send me a donation via Paypal.