

GAME ADJUSTMENTS: (1) LOCATE SWITCHES S1 THRU S32 ON MPU ASSEMBLY A4.
(2) SET SWITCHES FOR DESIRED PLAYFIELD CONDITIONS.
(3) TURN GAME OFF. THEN ON. ADJUSTMENTS ARE THEN COMPLETE.

BALLS PER GAME: 5-BALL - SET S16 to ON.
3-BALL - SET S16 to OFF.

SOUND OPTION: PLAY TUNES - SET S8 to ON.
NOISE - SET S32 to ON.
(OTHER SETTINGS: REFER TO INSTRUCTION MANUAL, PAGE 7)

MATCH FEATURE: ON - SET S21 to ON.
OFF - SET S21 to OFF.

CREDIT DISPLAY: DISPLAY ON - SET S20 to ON.
DISPLAY OFF - SET S20 to OFF.

-11

Font used: AlternateGothic2 BT
Card -11 Game Adjustments (size 205 x 83 mm) confirmed.

Enjoy and have fun,
Peter

www.inkochnito.nl

If you like my work, please send me a donation via Paypal.