GAME ADJUSTMENTS: (1) LOCATE SWITCHES S1 thru S32 on MPU ASSEMBLY A4.
                    (2) SET SWITCHES FOR DESIRED PLAYFIELD CONDITIONS.
                    (3) TURN GAME OFF. THEN ON. ADJUSTMENTS ARE THEN COMPLETE.

BALLS PER GAME: 5-BALL   -   SET   S16 to ON.
                    3-BALL   -   SET   S16 to OFF.

MELODY OPTION: PLAY TUNES - SET   S8 to ON.
                    SILENCE   - SET   S8 to OFF.

MATCH FEATURE: ON   -   SET   S21 to ON.
                    OFF   -   SET   S21 to OFF.

CREDIT DISPLAY: DISPLAY ON   -   SET   S20 to ON.
                    DISPLAY OFF   -   SET   S20 to OFF.

-3A

Font used: AlternateGothic2 BT
Card -3A Game Adjustments (size 205 x 83 mm) confirmed.

Enjoy and have fun,
Peter
www.inkochnito.nl
If you like my work, please send me a donation via Paypal.