

- The Phantom of the Opera**
- Skill Shot** Top Flashing Light on the plunge scores 100K X Ball Number and opens the **Organ**.
- Multiball** Complete 3 *Phantom Notes* to open **Organ** and Lock 2 Balls in time to go to **3-Ball Play**.
- Jackpot** In **3-Ball Play** shoot one (1) **Phantom Organ Target** and then shoot the **Phantom Organ** for the **Jackpot**.
- Unlimited Millions** Spell P-H-A-N-T-O-M by shooting the **Ramp**. When lit, shoot the **Ramp** for *Unlimited Million Shots*.
- Top Lanes** Top Lanes and **3-Ball Multiball** advances each **Jackpot**. Through the **Top Lanes** lights the 5K **Spinner**.
- Magic Mirror** The **Mirror** advances “2X”, “3X”, “4X” & “5X”. “6X” lights **Extra Ball**. “7X” lights **Bonus Hold**.
- Grasshopper & Scorpion** Completing the **Left** and **Right 3-Bank Targets** scores 50K, Bonus Hold, 100K, then lights **Extra Ball** and then lights **Special**.
- Trap Door** Shoot the **Trap Door** to score the **Mystery Value**.
- Double Score** Shoot the **Ramp** twice on the **Last Ball** to **Double Score**.

