

ADJUSTMENT OF COIN SWITCH FOR 10 CENTS PLAY

- 1. REPLACE SWITCH ARM A-4401 (25¢) WITH A-4400 (10¢) ENCLOSED IN THE INSTRUCTIONS ENVELOPE.**
- 2. ADJUST SPACING BETWEEN POINTS TO .018.**
- 3. ADJUST PRESSURE OF LONG BLADE AGAINST POINT OF CONTACT WITH WIRE FORM TO 5 GRAMS.**
- 4. ADJUST PRESSURE OF SHORT BLADE AGAINST POINT OF CONTACT TO 2 GRAMS. (MEASURED AT END OF BLADE.)**
THE TOTAL PRESSURE WITH SWITCH CLOSED MEASURED AT POINT OF CONTACT TO WIRE FORM AND INCLUDING .015 OVER TRAVEL (MAKE) SHOULD BE 9 GRAMS.

A-13354

Fonts used: News Gothic Std

Cards status:

A-13354 card confirmed.

If you have any other information about these cards, please send a readable picture or scan to me.

Enjoy and have fun,
Peter

www.inkochnito.nl

If you like my work, please send me a donation via Paypal.