

HIGH SCORE AWARD ADJUSTMENT

HIGH SCORE FEATURE: Free Game or Extra Ball for 1 or 2 Pre-Determined Scores

RECOMMENDED SCORE	1st	2nd
3 BALL	280,000	460,000
5 BALL	460,000	640,000

- (1) **VIEW HIGH SCORES:** Push and Release Red Self Test Button (Inside Front Cash Box) 5 Times. Number **01** will appear in the Match/Ball-In-Play Display and the 1st High Score will appear in the Players Display. Push Test Button again **02** and **2nd** High Score will appear.
- (2) **TO CHANGE SCORE:** Pressing Credit Button on Door will Advance **1st** or **2nd** High Score. To Change to Lower Score, Reset to "00", See (3) and Press Credit Button.
- (3) **RESET SCORE** (Any One or All): Do (1), Push S33 on MPU Assembly in Backbox. "00" will appear on Player Score Display.

HIGH GAME TO DATE FEATURE: Awards 3 Free Games. Recommended Starting Score — 3 Ball 500,000; 5 Ball 750,000. (Score will Advance Automatically as Higher Score is Achieved).

- (1) **VIEW HIGH GAME SCORE:** Same as (1) above, except press Test Button until "04" appears.
- (2) **CHANGE HIGH GAME SCORE:** Same as (2) above.
- (3) **RESET HIGH GAME SCORE:** Same as (3) above.

12A-155

Font used: Helvetica, CentSchbook Mono BT.

Card size: 140 x 127 mm
12A-155 High Score Award Adjustment card confirmed.

Enjoy and have fun,
Peter

www.inkochnito.nl

If you like my work, please send me a donation via Paypal.