

STAR GAZER SELF TEST DISPLAY NUMBERS

SELF-TEST

BUTTON LOCATED INSIDE OF COIN DOOR

NO. OF TIMES PUSHED	TEST	DESCRIPTION
1	BURN IN	All outputs tested
2	LAMPS	All feature lamps will flash on & off.
3	DISPLAY	All digits display 000000 thru 999999 then No. 8 shifts from left to right.
4	SOLENOIDS	Continuous sequence of solenoids pulsed, then all sounds pulsed. (Solenoid driver transistor "Q" number displayed as solenoid is pulsed.
5	SWITCHES (Flashing 0 if all switches open)	Switch I.D. No. displays if closed. (See chart for switch I.D. No.)
6 To 23	THRESHOLD & BOOKKEEPING	See Operating Manual.

SOLENOID IDENTIFICATION

SOLENOID & SDU "Q" TRANSISTOR NO.	SOLENOID LOCATION
1.....	LEFT SLINGSHOT
2.....	RIGHT SLINGSHOT
3.....	KNOCKER
4.....	LEFT BANK TARGET
5.....	TOP BANK TARGET
6.....	RIGHT BANK TARGET
7.....	LEFT THUMPER
8.....	MIDDLE THUMPER
9.....	RIGHT THUMPER
10.....	OUT-HOLE
11.....	OPEN
12.....	OPEN
13.....	OPEN
14.....	OPEN
15.....	FLIPPER RELAY
16.....	OPEN
17.....	OPEN
18.....	OPEN
19.....	COIN LOCK-OUT
20 THRU 29.....	SOUND

SWITCH IDENTIFICATION

SWITCH NO.	SWITCH LOCATION	SWITCH NO.	SWITCH LOCATION
1	COIN CHUTE #1 (LEFT)	21	SAGITTARIUS STAND-UP TARGET
2	COIN CHUTE #2 (CENTER)	22	LEFT BANK-LEFT TARGET
3	COIN CHUTE #3 (RIGHT)	23	LEFT BANK-MIDDLE TARGET
4	LEFT SPINNER	24	LEFT BANK-RIGHT TARGET
5	RIGHT SPINNER	25	TOP BANK-LEFT TARGET
6	CREDIT	26	TOP BANK-MIDDLE TARGET
7	TILT	27	TOP BANK-RIGHT TARGET
8	SLAM	28	RIGHT BANK-LEFT TARGET
9	SPINNER MIDDLE	29	RIGHT BANK-MIDDLE TARGET
10	GEMINI STAND-UP TARGET	30	RIGHT BANK-RIGHT TARGET
11	CANCER STAND-UP TARGET	31	CAPRICORN STAND-UP TARGET
12	LEFT THUMPER	32	AQUARIUS STAND-UP TARGET
13	RIGHT THUMPER	33	OUT HOLE
14	MIDDLE THUMPER	34	RIGHT OUT LANE
15	RIGHT SLINGSHOT	35	LEFT OUT LANE
16	LEFT SLINGSHOT	36	RIGHT STAR ROLL-OVER
17	LEO STAND-UP TARGET	37	LEFT STAR ROLL-OVER
18	VIRGO STAND-UP TARGET	38	PISCES STAND-UP TARGET
19	LIBRA STAND-UP TARGET	39	ARIES STAND-UP TARGET
20	SCORPIO STAND-UP TARGET	40	TAURUS STAND-UP TARGET

STAR GAZER SELF TEST DISPLAY NUMBERS

SELF-TEST

BUTTON LOCATED INSIDE OF COIN DOOR

NO. OF TIMES PUSHED	TEST	DESCRIPTION
1	BURN IN	All outputs tested
2	LAMPS	All feature lamps will flash on & off.
3	DISPLAY	All digits display 000000 thru 999999 then No. 8 shifts from left to right.
4	SOLENOIDS	Continuous sequence of solenoids pulsed, then all sounds pulsed. (Solenoid driver transistor "Q" number displayed as solenoid is pulsed.
5	SWITCHES (Flashing 0 if all switches open)	Switch I.D. No. displays if closed. (See chart for switch I.D. No.)
6 To 23	THRESHOLD & BOOKKEEPING	See Operating Manual.

SOLENOID IDENTIFICATION

SOLENOID & SDU "Q" TRANSISTOR NO.	SOLENOID LOCATION
1.....	LEFT SLINGSHOT
2.....	RIGHT SLINGSHOT
3.....	KNOCKER
4.....	LEFT BANK TARGET
5.....	TOP BANK TARGET
6.....	RIGHT BANK TARGET
7.....	LEFT THUMPER
8.....	MIDDLE THUMPER
9.....	RIGHT THUMPER
10.....	OUT-HOLE
11.....	OPEN
12.....	OPEN
13.....	OPEN
14.....	OPEN
15.....	FLIPPER RELAY
16.....	OPEN
17.....	OPEN
18.....	OPEN
19.....	COIN LOCK-OUT
20 THRU 29.....	SOUND

SWITCH IDENTIFICATION

SWITCH NO.	SWITCH LOCATION	SWITCH NO.	SWITCH LOCATION
1	COIN CHUTE #1 (LEFT)	21	SAGITTARIUS STAND-UP TARGET
2	COIN CHUTE #2 (CENTER)	22	LEFT BANK-LEFT TARGET
3	COIN CHUTE #3 (RIGHT)	23	LEFT BANK-MIDDLE TARGET
4	LEFT SPINNER	24	LEFT BANK-RIGHT TARGET
5	RIGHT SPINNER	25	TOP BANK-LEFT TARGET
6	CREDIT	26	TOP BANK-MIDDLE TARGET
7	TILT	27	TOP BANK-RIGHT TARGET
8	SLAM	28	RIGHT BANK-LEFT TARGET
9	SPINNER MIDDLE	29	RIGHT BANK-MIDDLE TARGET
10	GEMINI STAND-UP TARGET	30	RIGHT BANK-RIGHT TARGET
11	CANCER STAND-UP TARGET	31	CAPRICORN STAND-UP TARGET
12	LEFT THUMPER	32	AQUARIUS STAND-UP TARGET
13	RIGHT THUMPER	33	OUT HOLE
14	MIDDLE THUMPER	34	RIGHT OUT LANE
15	RIGHT SLINGSHOT	35	LEFT OUT LANE
16	LEFT SLINGSHOT	36	RIGHT STAR ROLL-OVER
17	LEO STAND-UP TARGET	37	LEFT STAR ROLL-OVER
18	VIRGO STAND-UP TARGET	38	PISCES STAND-UP TARGET
19	LIBRA STAND-UP TARGET	39	ARIES STAND-UP TARGET
20	SCORPIO STAND-UP TARGET	40	TAURUS STAND-UP TARGET