

GAME INSTRUCTIONS

CHOOSE YOUR CHARACTER: At the start of the game use the left flipper to select a character; LUKE, LEIA, HAN, or R2-D2.

Each character will:

- Spot missions changing your path through the game.
- Provide different skill shot selections.

SKILL SHOT SELECTION: At the start of each ball, use the right flipper button to change which award you will receive when you plunge the ball.

SHOT MULTIPLIERS: Use the ACTION BUTTON to toggle the shot multiplier ON or OFF. When OFF, use the flipper buttons to move the shot multiplier left or right. When ON, the lit shot will multiply all awards on the shot. Hit three bank targets to increase the multiplier. Shoot quickly before the multiplier expires.

HYPERSPACE HURRY-UP: Complete REBEL LANES to build Hurry-Up value and light Hyperspace Hurry-Up (yellow arrows). When lit, shoot either right ramp or left orbit to start the Hurry-Up. Shoot the left inner loop to complete it.

DESTROY TIE FIGHTERS: Hit three bank and other targets to destroy TIE Fighters. At thresholds of destroyed TIE Fighters the game will award: TIE FIGHTER HURRY-UP, TIE FIGHTER MULTIBALL, and LIGHT EXTRA BALL.

TIE FIGHTER MULTIBALL: Complete Jackpots to light Super Jackpot.

TIE FIGHTER HURRY-UP: Hit the target in front of the TIE Fighter TOY to complete the Hurry-Up. TIE FIGHTER ASSAULT will start when this feature is completed. START HITTING THE ACTION BUTTON!

TIE FIGHTER ASSAULT: Rapidly hit the ACTION BUTTON to destroy as many TIE Fighters as possible before the timer runs out.

INSTANT INFO: To start instant info hold one flipper button for a few seconds. While holding, use the other flipper button to find the desired information. Use the ACTION BUTTON to go back to the previous page.

© & ™ Lucasfilm Ltd.

755-51J5-12-Y English/Spanish

INSTRUCCIONES

SELECCIONÉ UN PERSONAJE: Use el botón "flipper" izquierdo para escoger uno de los protagonistas. Luke, Leia, Han, o R2-D2.
- Cada uno trae diferentes caminos dentro del juego.
- Cada uno presenta un objetivo especial.

"SKILL SHOT": Al comenzar la bola, use el botón derecho "flipper" para escoger entre varios premios iniciados una vez lancé la bola.

MULTIPLICADORES: Use el botón marcado "Acción" para iniciar o apagar las flechas que marcan el tiro que quiere aumentar. Use los botones "flipper" para mover las luces que ilumina las flechas. El valor multiplicado (indicado por la flecha iluminada) dura un tiempo limitado.

"HYPERSPACE HURRY-UP": Complete las carrileras marcadas con el símbolo de la "Alianza Rebelde" para aumentar el valor de la moda "Hurry-Up" y para iluminar las flechas amarillas para premios.

"DESTRUYA TIE FIGHTERS": Tire la bola contra los 3 blancos ("targets") para destruir "TIE Fighters". Los premios por cantidades de "TIE Fighters" destruidos son: "TIE FIGHTER HURRY-UP", "TIE FIGHTER" MULTE BOLA, e iluminar "BOLA EXTRA".

"TIE FIGHTER" MULTE BOLA: Complete los tiros iluminados para los premios "Jackpot" y para iluminar el premio "Super Jackpot".

TIE FIGHTER HURRY-UP: Dele al blanco bajo el juguete del "TIE Fighter" para completar la moda "Hurry-Up" e iniciar la moda "Asalto de los TIE Fighters".

"ASALTO DE LOS TIE FIGHTERS": Dele al botón marcado "Acción" rápidamente para destruir el máximo número de "TIE Fighters".

INFORMACIÓN INSTANTÁNEA: Aguante un botón "flipper" por un momento para ver información perteneciendo a su progreso en el juego. Existen varias páginas, use el botón "Acción" para ver las otras páginas.